

**Product Name :**  
Mixing Apparatus

**Product Code :**  
TEST5060RFQLAB-0009



**Description :**

Mixing Apparatus

**Technical Specification :**

Used for preparation of plastic mortar of cement and pozzolanic materials for making different types of test specimens in the laboratory.

The apparatus comprises the following :-

A motor-driven mixer which simultaneously imparts two motions to the mixing paddle i.e. revolving and planetary, they being opposite to one another in direction as per IS. A two speed gear box is incorporated in the drive which makes the paddle revolve at approximately 140 and 285 r.p.m. with corresponding planetary motion of 62 and 125 r.p.m. respectively.

A stainless steel mixing paddle of the specified shape and dimensions which can be attached or removed easily.

A stainless steel mixing bowl of about 6 litre capacity.

This can be held with the mixing apparatus and its height is adjustable.

A scraper made from semi rigid rubber blade attached to a handle about 150 mm long. The blade is about 75 mm long and 50 mm wide. Suitable for operation on 220v, 50 Hz, single phase supply.

We are a leading manufacturers of Mixing Apparatus testing equipment for a range of industries, including materials science testing lab. We offer full range of Mixing Apparatus testing equipment, including Mixing Apparatus testing kit, Mixing Apparatus testing machine, Mixing Apparatus testing tools, Mixing Apparatus test equipment, Mixing Apparatus test machines, Mixing Apparatus for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Mixing Apparatus testing equipment that helps customers build better, safer, and more

---

sustainable infrastructure.



## Testing lab instruments India