

**Product Name :**  
Point Load Tester Bench Type

**Product Code :**  
TEST5038RFQLAB-0002



**Description :**

Point Load Tester Bench Type for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

The unit comprises of a base frame on which the frame assembly with the integral jack and two load gauges with isolating valves are fixed. The ram of the jack carries the lower cone while the upper cross head has the other loading cone. The cones are made as per IS 8764. Spacer blocks are provided to test samples ranging from EX size to 100 mm size. Maximum clearance between the two cones is approx 125 mm. Lower range gauge of 25 kN is provided for better sensitivity and 100 kN gauge reaches upto the maximum capacity.

We are a leading manufacturers of Point Load Tester Bench Type testing equipment for a range of industries, including materials science testing lab. We offer full range of Point Load Tester Bench Type testing equipment, including Point Load Tester Bench Type testing kit, Point Load Tester Bench Type testing machine, Point Load Tester Bench Type testing tools, Point Load Tester Bench Type test equipment, Point Load Tester Bench Type test machines, Point Load Tester Bench Type for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Point Load Tester Bench Type testing equipment that helps customers build better, safer, and more sustainable infrastructure.

---

## Testing lab instruments India

