

**Product Name :**  
Liquid Limit Cone Penetrometer Automatic

**Product Code :**  
TEST5000RFQLAB-0004



**Description :**

Liquid Limit Cone Penetrometer Automatic

**Technical Specification :**

The unit meets the requirements This penetrometer Liquid Limit Cone Penetrometer except that the time of penetration of the cone is automatically controlled using a timing head and an Automatic Electronic Timer. The timer supplies 220 V smoothed D.C. output to the timing head precisely for 5 seconds to allow the cone to freely penetrate the soil in the trough. At the end of 5 seconds, the timer automatically de-energizes the releasing electromagnet and then relocks the cone. The reading is taken from the scale. This eliminates individual errors and gives consistence results. Suitable for operation on 220V, 50 Hz, single phase supply.

We are a leading manufacturers of Liquid Limit Cone Penetrometer Automatic testing equipment for a range of industries, including materials science testing lab. We offer full range of Liquid Limit Cone Penetrometer Automatic testing equipment, including Liquid Limit Cone Penetrometer Automatic testing kit, Liquid Limit Cone Penetrometer Automatic testing machine, Liquid Limit Cone Penetrometer Automatic testing tools, Liquid Limit Cone Penetrometer Automatic test equipment, Liquid Limit Cone Penetrometer Automatic test machines, Liquid Limit Cone Penetrometer Automatic testing Instruments. We are suppliers of materials testing tools equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Liquid Limit Cone Penetrometer Automatic testing equipment that helps customers build better, safer, and more sustainable infrastructure.



**Testing lab instruments India**