

**Product Name :**  
Core Drilling Compact Machine

**Product Code :**  
TEST5035RFQLAB-0001



**Description :**

Core Drilling Compact Machine for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

Compact and mobile, 'Core-drill' machine drills through hard rock, concrete, bitumen, tiles, marbles etc. and takes out cores for the preparation of laboratory samples.

Drive is through a powerful multi speed motor.

It can easily cut cores upto 150 mm dia.

The total assembly move on a pillar to adjust the tip height of the bit.

Pillar is fixed on to a base with two wheels for site shifting.

Geared motor moves on a slide and the slide can be rotated through 360°. Travel of the geared motor is approximately 600 mm and the cores of 400-450 mm can be easily taken out in single operation

Power of the Motor : 2500 Watts

Multiple Speeds (3 speeds) : 500,1200,2000 rpm

Power Supply : 230 Volts, 50 Hz AC.

Continuous Running time without damage to bits & barrels : 30 minutes

We are a leading manufacturers of Core Drilling Compact Machine testing equipment for a range of industries, including materials science testing lab. We offer full range of Core Drilling Compact Machine testing equipment, including Core Drilling Compact Machine testing kit, Core Drilling Compact Machine testing machine, Core Drilling Compact Machine testing tools, Core Drilling Compact Machine test equipment, Core Drilling Compact Machine test machines, Core Drilling Compact Machine for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate,

---

and easy-to-use Core Drilling Compact Machine testing equipment that helps customers build better, safer, and more sustainable infrastructure.



## Testing lab instruments India