

Product Name :
Calibration Anvil

Product Code :
TEST5176RTLBT-0037



Description :

Calibration Anvil

Technical Specification :

Calibration Anvil

The Schmidt Calibration Anvil is used to periodically the calibration of Type N and type L test hammers. This calibration anvil has a solid steel hammer guide, 6in (152mm) diameter anvil, and a hardened alloy steel rebound plate.

The impact surface of the rebound plate is concave so that the test hammer plunger seats completely in the impact surface of the anvil. A wire cleaning brush is included.

Specifications:

Solid steel construction

Steel Hammer Guide 6 inches diameter

Concave impact surface

Accessories:

Calibration anvil Adapter for the adjustment of Calibration Anvil to adapt to both Type N and Type L Schmidt Test hammers

Testing lab instruments India

