

Product Name :
Automatic Bituminous Compactor Electrically Operated

Product Code :
TEST5084RFQLAB-0001



Description :

Automatic Bituminous Compactor Electrically Operated for Testing Lab Equipment Tender Suppliers India

Technical Specification :

This Compactor automatically stimulates hand compaction as specified in ASTM D-1559 and develops a uniformity in the test procedure. The apparatus consists of a chain drive coupled to the motor through a gear box, and carries a locking device which lifts and releases the hammer through a specified height. Fitted with a counter which trips the motor automatically after 50 or 75 strokes as set on it. Suitable for operation on 220 V, 50 Hz, single phase supply.